


303-Fleet Quick start guide


Follow the steps on the quick user guide before you install the tracker



1 Locating the IMEI no.


- Locate the IMEI number of your tracker.
- This can be found printed on the box of the tracker.

If you are an existing user, log in and skip to step number 4.




2 Register your account

- Download the GPSLive app from the Apple App Store or Google Play Store.
- Open the app and tap on "Create New Account" Enter your email address and tap on "Register".



3 Accessing your account


- Check your email inbox/spam for an email from GPSlive which will contain your username and password.
- Open the GPSlive app and log in using the username and password provided in the email.



4 Add your device


- Tap on "Add Device"

If you are adding a new tracker to an existing account tap on "Devices", scroll all the way to the bottom of the page and tap on "Add Device".




5 Name your device

- Choose a name for your device and enter it in the field provided. You can change the name of your device at any time.
- Once done, tap on "next"




6 IMEI number

- Tap on "Scan IMEI barcode"
- If you are unable to scan the barcode, tap on "enter IMEI manually".



7 Scanning the IMEI

- Scan your tracker's barcode as shown above. Make sure that the whole barcode is within the green box.



8 Tracking

- Your device has been added and your 7 day trial has been activated.

To access the full version of GPSLive software, visit www.gpslive.co.uk from your computer or laptop.

Installation and FAQ's

Installation



We recommend the installation to be carried out by a professional auto electrician. The device should be connected to a permanent live feed.

If you only require location information, simply connect the RED - Power and BLACK - Ground cables only. The Ignition input (white) is optional and will monitor the ignition status of your vehicle.

The device should be installed with the logo side facing up as this is where the directional GPS receiver is located.

Do not install the device below thick metal surfaces as this will block the satellite signal. (e.g. inside the engine bay or the boot)

Ideal installation places are under the front dashboard or behind the glove box. (See below)



Wiring Diagram



1- RED:
PERMANENT LIVE POWER.
SUPPORTS FROM 10VDC UP TO 30VDC

2- BLACK:
GROUND/EARTH/CHASSIS

3- WHITE - IGNITION:
DEDICATED INPUT FOR IGNITION DETECTION.
MUST BE CONNECTED TO THE IGNITION WIRE
OR AN ACCESSORY THAT RECEIVES POWER
WITH THE IGNITION. (E.G. STEREO).

LED Lights

GPS LED - BLUE

Flashing: The device has established a GPS fix.
LED Off: No GPS Reception

GSM LED - GREEN

Solid: NO GSM mobile phone network reception
Flashing: The device has connected to the
GSM mobile phone network

POWER LED - RED

Solid: Device powered up & charging internal battery
Flashing fast: Internal battery low on power
LED Off: Internal battery is fully charged

Troubleshooting

Why is my tracker not updating it's location?

If this is the first time you are using your tracker, it may take a while to establish a GPS lock. Take your device for a quick drive to allow it to establish a GPS satellite fix. Ensure that the LED lights on the tracker are flashing and the device is installed with the logo side facing up as this is where the directional GPS receiver is located.

Will the tracker drain my vehicle's battery?

The 303 uses around 200mAh power while your vehicle is moving and 60mAh while your vehicle is stationary (standby mode). It will normally take approximately 6-8 weeks to completely drain the battery of a vehicle that's never used.

Are there any hidden charges or costs?

The only ongoing cost is the service top-up, which includes GPSLive software, GPSLive app and mobile internet, which allows your device to operate in more than 120 countries (including all EU countries) without paying extra roaming charges.

↑
This way up

